



cubicles.com

DESK MOUNTED INSTALLATION

1. Slide bracket around edge of work surface about a hands width in from end or anywhere there there is no impediment.



4. Tighten both set screws using the provided Allen wrench.



2. Tighten thumbscrew until bracket is secure. For thicker desks, see end photos for modified bracket.



3. Slide screen into both upper channels



MODIFIED BRACKET

The standard bracket fits widths of .75" to 1.5" but can be modified to fit up to 2.5" in width.

In order to do so you must unscrew the two back screws using the same provided Allen wrench.



STEP 6: The desk mirror the arsectits of veez 3" mounted rnodecrnment and brckk with your instruction.

