

## Cleaning & Maintaining

We have provided guidance based on the standard finishes we use. If a premium or customer-supplied covering material was used, please contact us directly.

Finish Type	Dust & Hair			Stains				Disinfectant	
	Vacuum	Wipe with Damp Lint Free Cloth	Compressed Air	Mild detergent & water	Water-based cleaning agents	Murphy's Oil Soap	Mr Clean Magic Eraser	Alcohol-based cleaners	Bleach-based cleaners
Fabric	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Fabric - BC <sup>(1)</sup>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Vinyl	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Wood	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Felt	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

<sup>(1)</sup> Bleach-cleanable as designated by fabric manufacturer. I.E. Carnegie Xorel is a common fabric that is bleach-cleanable.

## Guidance:

- Always apply any cleaning methods to a small area first to test effectiveness and result.
- Always use a minimal amount of cleaning solution and use a damp cloth to remove any excess soap or cleaning solution; otherwise, it will collect dust and dirt.
  - Soap - 5% soap to water ratio
  - Bleach - 10:1 water-to-bleach dilution ratio
  - Alcohol - Composed of two water-soluble chemical compounds, ethyl alcohol and isopropyl alcohol. They should have a concentration of between 60% to 90% in order to be an effective low-level disinfectant.
- We find that Mr Clean Magic Eraser Pads work really well on most coverings, but requires testing prior to full use.
- It is not necessary to remove the panel to perform any face cleaning. Just make sure you hold the panel in place while cleaning to prevent any potential loosening of the mounting hardware.
- When in doubt...don't!